DTA Remote Quick Tips

*UPDATED REMOTE MODEL

Turns cable box ON/OFF

Turns TV ON/OFF

HOLD for 3 seconds to enter the PROGRAM menu

Displays main cable MENU

Displays program GUIDE

OK/ENTER selects highlighted option

Displays INFO and currently selected program

EXITS menu and returns to current program

Returns to LAST channel you were watching

Controls and MUTEs TV VOLUME

Move up and down among CHANNELS

Turn CLOSED CAPTIONING on and off

Select available video components from a list of INPUTs

UR2-DTA-RF4