DTA Remote

POWER

OK

PAGE

GUIDE

INFO

0

EXIT

6

LANG

MOTOROLA

MENU

Turns TV ON/OFF

Displays program GUIDE

OK/ENTER selects highlighted option

Displays INFO and currently selected program

Controls and MUTEs TV VOLUME

Returns to LAST channel you were watching

HOLD for 3 seconds to enter the SETUP menu Turns cable box ON/OFF

Displays main cable MENU

EXITS menu and returns to current program

Acces PAGE above or below the information currently displayed

Move up and down among CHANNELS