# Universal Remote

**TV, AUD, DVD, VCR, STB**
Use one remote to control multiple devices.

**SETUP**
Use for programming sequences of devices controlled by the remote.

**VIDEO CONTROLS**
In STB mode, these control the DVR functions. In other modes, these can control a VCR or DVD.

**MENU**
Displays the menu.

**GUIDE**
Opens the Interactive Program Guide.

**DAY +/-**
Jump ahead or back one day in the Interactive Program Guide.

**WEATHER**
- Weather
- Forecast
- Radar
- Animate (makes radar move)

**VOL +/-**
Raise or lower the volume.

**FAV**
View your favorite channels.

**MUTE**
Turn the sound off or on.

*** ASPECT RATIO**
Temporarily change the conversion mode from Original Size or Fit to Screen.

**INPUT**
In TV control mode, will change the input of the device you are controlling

**POWER**
Turn on/off a selected device.

**LIVE**
Return to watching live TV.

**INFO**
Display the current channel and program information. Press again for more detail.

**ARROW KEYS**
Navigate and select on screen choices.

**EXIT**
Exit the current screen.

**PAGE +/-**
Page up or down in lists and Interactive Program Guide.

**CHANNEL +/-**
Changes to the next higher or lower channel.

**LAST**
Recall the last channel or option.

**NUMBER KEYS**
Directly select a channel or enter options.